

## MacFab Type Balers and Drum Crushers – Basic Troubleshooting Steps

- If machine will not power up when switched on – check machine is plugged in and circuit breaker at switchboard is not tripped.
- Check e-stop; if it has been pressed, please reset by rotating to release and press blue reset button
- If machine is powered but will not operate check all doors are fully shut and latched.
- If blue lamp/ button is illuminated press the blue reset button and use UP button to return press plate to home position
- If green and amber lights are flashing it means that the motor overload has tripped. Get a competent person such as site electrician or engineer to open main electrical cabinet and press the reset button on the Q1 block to reset.

No Joy? Call us back Free on 0508 474 663 and ask for a  
Service Technician Callout

